



Position where required, install undercover, mounting hardware supplied

Your supply of cable, fittings supplied

Probe factory calibrated to specified depth on order

Probe to sit at base of tank

Plug in supplied power cord and connect to mains power



eNICKO
ELECTRONIC LEVEL INDICATOR

TANK HEIGHTS TO 5M

ADVANTAGES

- SIMPLE TO INSTALL
- HARD WIRED PERFECT FOR REMOTE READING
- SUITABLE FOR UNDERGROUND TANKS

